



General Machinery Safety Instructions

Machinery House
requires you to read this entire Manual before using this machine.

1. Read the entire Manual before starting machinery. Machinery may cause serious injury if not correctly used.

2. Always use correct hearing protection when operating machinery. Machinery noise may cause permanent hearing damage.

3. Machinery must never be used when tired, or under the influence of drugs or alcohol. When running machinery you must be alert at all times.

4. Wear correct Clothing. At all times remove all loose clothing, necklaces, rings, jewelry, etc. Long hair must be contained in a hair net. Non-slip protective footwear must be worn.

5. Always wear correct respirators around fumes or dust when operating machinery. Machinery fumes & dust can cause serious respiratory illness. Dust extractors must be used where applicable.

6. Always wear correct safety glasses. When machining you must use the correct eye protection to prevent injuring your eyes.

7. Keep work clean and make sure you have good lighting. Cluttered and dark shadows may cause accidents.

8. Personnel must be properly trained or well supervised when operating machinery. Make sure you have clear and safe understanding of the machine you are operating.

9. Keep children and visitors away. Make sure children and visitors are at a safe distance for you work area.

10. Keep your workshop childproof. Use padlocks, Turn off master power switches and remove start switch keys.

11. Never leave machine unattended. Turn power off and wait till machine has come to a complete stop before leaving the machine unattended.

12. Make a safe working environment. Do not use machine in a damp, wet area, or where flammable or noxious fumes may exist.

13. Disconnect main power before service machine. Make sure power switch is in the off position before re-connecting.

14. Use the Correct Extension Lead. Extension leads should be avoided where possible but If required,

always use an extension lead that is rated for the power requirements of your machinery. Using an incorrectly rated extension lead can lead to overheating, damage to machinery, or potential fire hazards. Ensure leads are in good condition and free of damage. Replace if faulty.

15. Keep machine well maintained. Keep blades sharp and clean for best and safest performance. Follow instructions when lubricating and changing accessories.

16. Keep machine well guarded. Make sure guards on machine are in place and are all working correctly.

17. Do not overreach. Keep proper footing and balance at all times.

18. Secure workpiece. Use clamps or a vice to hold the workpiece where practical. Keeping the workpiece secure will free up your hand to operate the machine and will protect hand from injury.

19. Check machine over before operating. Check machine for damaged parts, loose bolts, Keys and wrenches left on machine and any other conditions that may effect the machines operation. Repair and replace damaged parts.

20. Use recommended accessories. Refer to instruction manual or ask correct service officer when using accessories. The use of improper accessories may cause the risk of injury.

21. Do not force machinery. Work at the speed and capacity at which the machine or accessory was designed.

22. Use correct lifting practice. Always use the correct lifting methods when using machinery. Incorrect lifting methods can cause serious injury.

23. Lock mobile bases. Make sure any mobile bases are locked before using machine.

24. Allergic reactions. Certain metal shavings and cutting fluids may cause an allergic reaction in people and animals, especially when cutting as the fumes can be inhaled. Make sure you know what type of metal and cutting fluid you will be exposed to and how to avoid contamination.

25. Call for help. If at any time you experience difficulties, stop the machine and call you nearest branch service department for help.



Motorcycle Lifter Safety Instructions

Machinery House
requires you to read this entire Manual before using this machine.

- 1. Maintenance.** Check oil levels and fill to correct oil levels if necessary.
- 2. Motorcycle Lifter Condition.** The Motorcycle Lifter must be maintained for a proper working condition. Never operate a Motorcycle Lifter that has low oil levels, damaged or worn parts. Scheduled routine maintenance should be performed on a scheduled basis. Check frame, welds, wheels & motorcycle wheel clamp for cracks or damage. Replace if necessary.
- 3. Crushing Hazard.** Never place any part of your body in the lifting mechanism or under the table as serious injury can occur. Always ensure the safety bar is either inserted or lowered before working on your motorcycle.
- 4. Work area hazards.** Keep the area around the Motorcycle Lifter clean from oil, tools, objects & chips. Pay attention to other persons in the area and know what is going on around the area to prevent unintended accidents.
- 5. Wheel Clamp System.** Always support the motorcycle during loading & unloading. Secure wheel lock & fix tie down straps to motorcycle before any work is carried out. Regular checking that your motorcycle is securely fixed to lifter should take place.
- 6. Overloading Motorcycle Lifter.** Check your motorcycle manual for the total weight. Do not overload the Motorcycle Lifter capacity.
- 7. Warning Labels.** Take note of any warning labels on the machine and do not remove them.
- 8. Material Hazard.** Do not lift objects that are not secured properly. If they fall serious injury can occur.
- 9. Safe Surface Use.** Only use the Motorcycle Lifter on hard, flat surfaces. Avoid using the Motorcycle Lifter on inclines or ramps that will cause a loss of control.
- 10. Safe Operation.** Use extreme care when handling loads. Always centre and support the Motorcycle during loading and unloading. Ensure front wheel is securely fixed in wheel lock. Always keep heavy loads on Motorcycle Lifter as close to the ground as possible for maximum stability at all times. Always ensure safety bar is inserted or lowered into position and feet are extended to maximum width if available before working on your Motorcycle. Leave the Motorcycle Lifter all the way down when not in use.
- 11. Other Hazards.** Never allow children to play on this Motorcycle Lifter, and never carry passengers!
- 12. Pinching.** Prevent pinching by releasing pressure in the ram leaving table all the way down when not in use.
- 13. Use Correct Air Pressure** Exceeding the maximum PSI rating of motorcycle lifter may cause unpredictable operation, injury and damage to machine. If this rating is not stated in manual suggest NOT to exceed 125psi. *(Applies to Pneumatic model only).*
- 14. Disconnect Air Pressure** before servicing Motorcycle Lifter, or leaving unattended. Always disconnect Air and ensure safety bar is inserted or lowered into position. *(Applies to Pneumatic model only).*
- 15. Air Hose - Trip Hazard** Hoses can easily become a tripping hazard when laid across the floor in a disorganized fashion. *(Applies to Pneumatic model only).*
- 16. Call for help.** If at any time you experience difficulties, stop the machine and call you nearest branch service department for help.

PLANT SAFETY PROGRAM
NEW MACHINERY HAZARD IDENTIFICATION, ASSESSMENT & CONTROL

Motorcycle Lifter

Developed in Co-operation Between A.W.I.S.A and Australia Chamber of Manufactures
This program is based upon the Safe Work Australia, Code of Practice - Managing Risks of Plant in the Workplace (WHSA 2011 No10)

Item No.	Hazard Identification	Hazard Assessment	Risk Control Strategies (Recommended for Purchase / Buyer / User)
B	CRUSHING	HIGH	Ensure use motorcycle lifter is on even, solid ground. Ensure motorcycle is securely fixed to platform. Keep body clear from under motorcycle lifter at all times. Do not exceed maximum lifting capacity of motorcycle lifter. Always check around motorcycle lifter before lowering. Check motorcycle lifter for cracks etc, prior to lifting. Ensure load is lowered smoothly. Wear safety boots. Do not exceed recommended maximum PSI rating. (applies to Pneumatic model only)
D	SHEARING	MEDIUM	Keep body parts clear between moving components of trolley when lowering.
G	HIGH PRESSURE AIR	MEDIUM	Disconnect air supply to motorcycle lifter prior to checks or maintenance. Do not exceed recommended maximum PSI rating. (applies to Pneumatic model only)
J	SLIPPING, TRIPPING, & FALLING	LOW	Avoid using motorcycle lifter on and around uneven or slippery surfaces.
Plant Safety Program to be read in conjunction with manufactures instructions			



www.machineryhouse.com.au



www.machineryhouse.co.nz

Authorised and signed by:

Safety officer:

Manager:




Revised Date: 2nd June 2025